	fortwo cabrio	fortwo cabrio BRABUS	fortwo coupé	fortwo coupé BRABUS	roadster	roadster- coupé	roadster BRABUS	forfour
Vehicle diagnosis								
Carry out a short test with diagnosis test equipment	•	•	•	•	•	•	•	•
Reset maintenance interval display in instrument cluster	•	•	•	•	•	•	•	•
Check crash line for airbag	•	•	•	•	•	•	•	-
Locking system								
Check functioning of central locking system	•	•	•	•	•	•	•	•
Check functioning of electronic immobiliser	•	•	•	•	•	•	•	-
Doors and soft top								
Grease and oil hinges and locks of doors and flaps	•	•	•	•	•	•	•	-
Grease and oil A-post strut support	-	-	-	-	•	•	•	-
Check functioning and condition of electrical soft top	•	•	-	-	•	•	•	-
Clean soft top guide	•	•	-	-	•	•	•	-

	fortwo cabrio	fortwo cabrio BRABUS	fortwo coupé	fortwo coupé BRABUS	roadster	roadster- coupé	roadster BRABUS	forfour
Passenger compartment								
Check handbrake play	•	•	•	•	•	•	•	•
Check battery and fluid level and correct (if necessary)	•	•	•	•	•	•	•	-
Check condition of battery terminals as well as the connections for secure fit	•	•	•	•	•	•	•	-
Check the feed line of the battery for proper routing and for chafe marks	•	•	•	•	•	•	•	-
Check seat belts and belt buckles for external damage and proper functioning	•	•	•	•	•	•	•	•
Check seat rail and backrest of the front passenger seat for correct latching	•	•	•	•	•	•	•	-
Check functioning of heater and ventilation	•	•	•	•	•	•	•	•
Check functioning of indicator lamps, symbol lighting and interior lights	•	•	•	•	•	•	•	•
Check functioning of horn	•	•	•	•	•	•	•	•
Check functioning of other electrical consumers	•	•	•	•	•	•	•	•
Lighting system								
Check functioning of front, rear and side lighting	•	•	•	•	•	•	•	•
Check functioning of signal lights, hazard warning flashers and headlight flashers	•	•	•	•	•	•	•	•
Check headlight beam setting and correct (if necessary)	•	•	•	•	•	•	•	•
Check functioning of headlight range adjustment	•	•	•	•	-	-	-	•

	fortwo cabrio	fortwo cabrio BRABUS	fortwo coupé	fortwo coupé BRABUS	roadster	roadster- coupé	roadster BRABUS	forfour
Cleaning the windows								
Check functioning of windscreen washer system and spray surface	•	•	•	•	•	•	•	•
Check condition and functioning of front and rear windscreen wipers	•	•	•	•	•	•	•	•
Windscreen washer system: Check fluid level and correct (if necessary)	•	•	•	•	•	•	•	•
Engine compartment								
Check exhaust system for leaks and secure fit	•	•	•	•	•	•	•	•
Check combination valve for leaks	•	•	•	•	•	•	•	-
Check exhaust gas recirculation for leaks (diesel engine)	•	-	•	-	-	-	-	-
Replace engine oil and oil filter	•	•	•	•	•	•	•	•
Check supply air ducting of charge air cooler for damage	•	•	•	•	•	•	•	-
Check V-belt for wear and damage	•	•	•	•	•	•	•	•
Check engine visually for damage and leaks	•	•	•	•	•	•	•	•
Replace spark plugs (only in petrol engine).	-	$ullet^1$	-	lacksquare1	$ullet^1$	lacksquare1	lacksquare1	-
Check fuel system visually for damage and leaks	•	•	•	•	•	•	•	•
Replace combination filter (with air conditioning only)	-	-	-	-	-	-	-	•

 $^{^{1}}$ additional service scope against a separate invoice if there is a difference of more than 30,000 km from the last change

	fortwo cabrio	fortwo cabrio BRABUS	fortwo coupé	fortwo coupé BRABUS	roadster	roadster- coupé	roadster BRABUS	forfour
Coolant system								
Check engine cooling system for leaks	•	•	•	•	•	•	•	•
Check hoses for proper routing and for damage	•	•	•	•	•	•	•	-
Transmission								
Check transmission visually for damage and leaks	•	•	•	•	•	•	•	•
Check oil level in transmission and correct (if necessary)	•	•	•	•	•	•	•	•
Check clutch actuator for play	•	•	•	•	•	•	•	-
Check axle shaft sleeves for damage	•	•	•	•	•	•	•	•
Axles/underside of vehicle								
Check underside of vehicle visually for damage	•	•	•	•	•	•	•	•
Check tie rod and drag link joints play, check rubber boots	•	•	•	•	•	•	•	•
Check rubber bearings and joints for damage	•	•	•	•	•	•	•	•
Check supporting joints	•	•	•	•	•	•	•	-
Steering								
Check steering shaft/steering gear nut	•	•	•	•	•	•	•	-
Check steering boots for damage	•	•	•	•	•	•	•	•
Check tie rod and drag link joints play, check rubber boots	•	•	•	•	•	•	•	•

	fortwo cabrio	fortwo cabrio BRABUS	fortwo coupé	fortwo coupé BRABUS	roadster	roadster- coupé	roadster BRABUS	forfour
Brake system								
Brake fluid: Check fill level and condition	•	•	•	•	•	•	•	•
Brake hoses/brake lines: check for damage, proper routing and leaks	•	•	•	•	•	•	•	•
Front brake pads: check lining thickness	•	•	•	•	•	•	•	•
Brake discs: check condition	•	•	•	•	•	•	•	•
Brake callipers: check for leaks	•	•	•	•	•	•	•	-
Brake callipers: check screws for correct torque	•	•	•	•	•	•	•	-
Brake cables: check for damage, smooth running and proper routing $\label{eq:cables} % \begin{center} c$	•	•	•	•	•	•	•	•
Rear brake pads: check lining thickness	•	•	•	•	•	•	•	•
Wheels								
Check tyres and rims (including spare wheel) for damage and crack formation	•	•	•	•	•	•	•	•
Check tread depth (including spare wheel)	•	•	•	•	•	•	•	•
Check tyre pressure (including spare wheel) and correct (if necessary)	•	•	•	•	•	•	•	•
Wheel bolts: check for correct torque	•	•	•	•	•	•	•	•

	fortwo cabrio	fortwo cabrio BRABUS	fortwo coupé	fortwo coupé BRABUS	roadster	roadster- coupé	roadster BRABUS	forfour
Accessories								
Breakdown set: Check compressor for proper functioning	•	•	•	•	•	•	•	-
Breakdown set: Check date of expiry on tyre sealant and replace (if necessary)	•	•	•	•	•	•	•	-
First aid pouch – check date of expiry	•	•	•	•	•	•	•	•
Final inspection/test drive								
Brake test on dynamometer/during test drive	•	•	•	•	•	•	•	•
Check parking brake and bed in in accordance with regulations	•	•	•	•	•	•	•	•